


# Model DSD180 CORDLESS DRYWALL SAW



# Model DSD180 CORDLESS DRYWALL SAW

Strana 1 / 2

Položka	Objednávacie	Popis	I/C	ks	N/O	Možnosť 1	Možnosť 2	Poznámka
001	266130-9	SKRUTKA SAMOREZNÁ BIND3X16		3				
002	183C66-4	DUST COLLECTOR SET		1				
D10		INC. 5						
003	456628-6	HOOK		1				
004-1	231661-7	TORSION SPRING 9		1				
005	183C66-4	DUST COLLECTOR SET		1				
D10		INC. 2						
006	326680-7	SAFETY WIRE		1				
007	852N21-0	DSD180 NAME PLATE		1				
008	183E41-2	HOUSING SET		1				
C10	263002-9	KOLÍK GUMA 4		1				
C20	263005-3	KOLÍK GUMA 6 2414		2				
D10		INC. 30						
009	266326-2	SKRUTKA SAMOREZNÁ		9				
010	689098-6	HEAT SINK		1				
011	911013-5	PAN HEAD SCREW M3X10		1				
012	456625-2	LOCK OFF BUTTON		1				
013	650762-6	SWITCH		1				
014	140963-9	SWITCH PLATE COMPLETE		1				
015	620509-2	LIGHT CIRCUIT		1				
016	644808-8	TERMINAL		1				
018	421940-3	KRYTKA 8390D/8391DWAE/DWALE		1				
019	629193-0	DC MOTOR		1				
020	143694-9	SLIDER COMPLETE		1				
C10	256305-8	PIN 4		1				
C20	257391-2	RING 4		1				
C30	310686-5	SLIDER PLATE		1				
C40	310687-3	SLIDER GUIDE		1				
021	347010-9	BLADE HOLDER		1				
022	922106-3	IMBUSOVÁ SKRUTKA M4x8		2				
023	211012-0	LOŽISKO GULIČKOVÉ 606ZZ		1				
024	326679-2	SHOULDER WASHER		1				
025	212077-5	LOŽISKO IHLIČKOVÉ DCS230T		1				
026	143690-7	CRANK SHAFT COMPLETE		1				
027	211032-4	LOŽISKO GULIČKOVÉ 608ZZ		1				
028	456623-6	BASE		1				
029	911128-8	SKRUTKA M4x16		2				
030	183E41-2	HOUSING SET		1				
C10	263002-9	KOLÍK GUMA 4		1				
C20	263005-3	KOLÍK GUMA 6 2414		2				
D10		INC. 8						
031	123559-1	DUST COLLECTOR ASSEMBLY		1				
D10		INC. 1-3,4-1,5,32-34						
032	213412-0	O RING 29		1				
033	286268-4	CAP 31		1				
034	451177-8	DUST NOZZLE		1				
035	688165-4	LINE FILTER		1				
A01	456624-4	BASE COVER		1				

